



Dear Motorcyclist,

with this catalogue we offer assembly sets for steering head bearings as well as wheel bearing sets for motorcycles.

Each assembly set for the steering head consists of two taper roller bearings, upper and lower seal, adjusting washers, special bearing grease and a detailed assembly instruction. The assembly set can be changed against the standard bearings without any changes at the motorcycle.

The dimensions of the bearings (inner diameter, outer diameter, total bearing height in millimetre) are listed for information.

For Aprilia, Benelli, Ducati, MV, Moto Guzzi as well as for specified Kawasaki types we also offer the standard angular contact ball bearings as listed.

All offered bearings are original equipment manufacturer brand.

For order, please send us an e-mail with your postal address and name the item number you want to order.

We will send you an order confirmation including cost for packing and shipment.

Together with the parts you will receive the invoice.

Parts list version March 1st 2014.

The prices shown in the list are Euro prices and include the valid German VAT.

The listed prices are for the complete set. For angular contact ball bearings the set is without seals.



Advantages of the steering head bearing assembly with taper roller bearings

The bearing of the steering head with taper roller bearings will result in a stiffer bearing and by this in a higher stability of the motorcycle in acceleration, braking and turning into a corner.

During deceleration the stiffer bearing arrangement will allow the contact surface of the tire to the street (tread shuffle) to transmit the braking and steering forces precise. With a conventional bearing arrangement, sport driver operation characteristic and worn out or wrong set steering head bearings there may be an insufficient contact between tire and street. This may result in a lack of grip and may cause an accident.

The turning of the motorcycle into a corner will be more precise with the use of the taper roller bearing set. Rocking motion during strong acceleration of the motorcycle, that may be a result of a "soft" steering head bearing assembly, will be avoided by the use of the taper roller bearings.

The bearing lifetime of the taper roller bearings is even higher than the lifetime of the angular contact ball bearings because of the higher dynamic load rating of the taper roller bearings. The higher stiffness of the taper roller bearing arrangement is a result of the line contact of the rollers to the bearing raceways compared to the point contact of the balls to the raceways of the angular contact ball bearings.

The bearing of the steering head with taper roller bearings is a standard on old motorcycles as well as on racing motorcycles. On motorcycles with conventional steering head bearings the conversion to taper roller bearings often will be done on motorcycles that are driven in sportive driving characteristic. Considering the listed benefits it may make sense to change to taper roller bearing assembly also for street use.



Item-No.	Brand	Type	Upper bearing	Lower bearing	Set price €
Aprilia					
09-1000	Aprilia	Aprilia standard angular contact ball bearings	35x55x14,5	35x55x14,5	59,-
09-1001	Aprilia	Aprilia various - please check the dimensions of the assembled bearings	35x55x14	35x55x14	59,-
09-1001	Aprilia	Aprilia Falco	35x55x14	35x55x14	59,-
09-1001	Aprilia	Aprilia Falco SL	35x55x14	35x55x14	59,-
09-1001	Aprilia	Aprilia RST Futura	35x55x14	35x55x14	59,-
09-1001	Aprilia	Aprilia RSV Mille ME	35x55x14	35x55x14	59,-
09-1001	Aprilia	Aprilia RSV Mille R, (RP)	35x55x14	35x55x14	59,-
09-1001	Aprilia	Aprilia Tuono (RP)	35x55x14	35x55x14	59,-
09-1001	Aprilia	Aprilia Tuono RR 1000	35x55x14	35x55x14	59,-
09-1001	Aprilia	Aprilia Tuono RSV 1000	35x55x14	35x55x14	59,-
Benelli					
09-1000	Benelli	Benelli standard angular contact ball bearings	35x55x14,5	35x55x14,5	59,-
09-1001	Benelli	Benelli various - please check the dimensions of the assembled bearings	35x55x14	35x55x14	59,-
09-1001	Benelli	Benelli TnT 1130	35x55x14	35x55x14	59,-
BMW					
09-1002	BMW	BMW K 100 (K100)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW K 100 LT (K100LT)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW K 100 RS (K100RS)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW K 100 RS/RT (K100RS/RT)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW K 1200 LT (K1200LT)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW K 1200 LT (K2LT)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW K 1200 R (0584)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW K 1200 S (K1200S)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW K 75 /C (K75C)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW K 75 RT /ULTIMA (K75RT)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW K 75 S (K75S)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 100 GS (R100GS)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 100 GS PD (R100GS/PD)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 100 R (R100R)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 100 RS (0306)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 100 RS (0377)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 100 RS (R100RS)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 100 RT (0446)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 100 RT (R100RT)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 100 S (0305)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 100 S (0324)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 100 S (0376)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 100 T (0385)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 100/7 (0304)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1100 GS (R1100GS)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1100 R (R1100R)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1100 RS (R1100RS)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1100 RS (R1100RS/06)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1100 RS-SE (R1100RS-SE)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1100 RT (R1100RT)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1100 S (WB10)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1100 S /CUP (WB10/04)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1150 GS (R21)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1150 R (R1150R)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1150 R ROCKST (308)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1150 RS (0447)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1150 RT (0413)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1200 C (R1200C)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1200 CL (442)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1200 GS (0307)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1200 RT (R1200RT)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1200 ST (R1200ST)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 1200C MONTAUK (R12C-MONT)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 23 (0223/1)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 24 (0224/1)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 25 (R25)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 27 (R27)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 35 (0235)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 45 (0351)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 45 (0354)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 45 (248) (0355)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 50 S (0252/3)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 50/5 (0240)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 51/3 (0252/1)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 60/5 (0250)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 60/6 (0251)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 60/7 (0301)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 65 (0353)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 65 (0358)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 65 (R65)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 65 G/S (R65G/S)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 66 (0266/1)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 67/2 (0267/2)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 68 (0268/1)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 69 S (0268/3)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 71 (0271/1)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 75 M.SEITENW. (0275/2)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 75/5 (0260)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 75/7 (0302)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 80 G/S (0423)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 80 GS (R80GS)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 80 R (R80R)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 80 RT (0444)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 80 RT (247)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 80 ST (0347)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 80/7 N (0327)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 850 C (R259C)	28x52x16,5	28x52x16,5	45,-

09-1002	BMW	BMW R 850 GS (R259)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 90 S (R90S)	28x52x16,5	28x52x16,5	45,-
09-1002	BMW	BMW R 90/6 (0271)	28x52x16,5	28x52x16,5	45,-
Ducati					
09-1000	Ducati	Ducati standard angular contact ball bearings	35x55x14,5	35x55x14,5	59,-
09-1001	Ducati	Ducati various - please check the dimensions of the assembled bearings	35x55x14	35x55x14	59,-
09-1001	Ducati	Ducati 1198	35x55x14	35x55x14	59,-
09-1001	Ducati	Ducati 748	35x55x14	35x55x14	59,-
09-1001	Ducati	Ducati 916	35x55x14	35x55x14	59,-
09-1001	Ducati	Ducati Monster 1000 ie	35x55x14	35x55x14	59,-
09-1001	Ducati	Ducati Monster 1100	35x55x14	35x55x14	59,-
09-1001	Ducati	Ducati Monster S2R 1000	35x55x14	35x55x14	59,-
09-1001	Ducati	Ducati Monster S4R	35x55x14	35x55x14	59,-
09-1001	Ducati	Ducati multistrada	35x55x14	35x55x14	59,-
09-1001	Ducati	Ducati Streetfighter	35x55x14	35x55x14	59,-
Honda					
09-1006	Honda	Honda CB 1000 Big (SC30)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CB 1000 Big (SC30)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda CB 1100 F (SC11)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda CB 1100 R /SC08 (SC05)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CB 1300 (SC54)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CB 1300 / ABS (SC54/05)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CB 1300 S ABS (CB1300S)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CB 1300 X4 (SC38)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CB 450 S (PC17)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CB 500 (PC32)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CB 500 /S/CUP (CB500S)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CB 600 F Hornet (PC34)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CB 600 F Hornet (PC36)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CB 600 F Hornet (PC36/05)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CB 600 F Hornet (PC41)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda CB 750 C (RC06)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda CB 750 F A/B/C/2 (RC04)	26x47x15	30x55x17	59,-
09-1005	Honda	Honda CB 750 KZ,KA,KB (RC01)	25x47x15	30x55x17	45,-
09-1007	Honda	Honda CB 750 Night Hawk (RC38)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CB 900 F Hornet (SC48)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda CB 900 FB (SC01/81)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda CB 900 FC/FIIC (SC09)	26x47x15	30x55x17	59,-
09-1005	Honda	Honda CB 900 FZ/FA (SC01)	25x47x15	30x55x17	45,-
09-1007	Honda	Honda CB Seven Fifty F2 (RC42)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBF 1000 (SC58A)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBF 600 / ABS (PC38)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBF 600 S / ABS (PC38/S)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 1000 F (SC21)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 1000 F (SC24)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 1000 F Dual (SC24/94)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 1000 F/Dual (SC24/96)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 1000 RR (SC57)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 1000 RR (SC57/06)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 1100 XX (SC35/99)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 1100XX SC35 (CBR1100XX)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 600 F (PC19)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 600 F (PC23)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 600 F (PC25)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 600 F (PC31)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 600 F (PC35)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 600 F (PC35/01)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 600 F Sport (PC35FS/01)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 600 RR (PC37)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 600 RR (PC37/05)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 600 RR (PC40)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 600 RR/ABS (PC40/09)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 900 RR (SC28)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 900 RR (SC33)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda CBR 900 RR (SC33/98)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda CBR 900 RR (SC44)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda CBR 900 RR (SC50)	26x47x15	30x55x17	59,-
09-1005	Honda	Honda CBX 1000 (CB1) Bj. '78-79	25x47x15	30x55x17	45,-
09-1006	Honda	Honda CBX 1000 (SC06) Bj. '80-83	26x47x15	30x55x17	59,-
09-1005	Honda	Honda CBX 750 F	25x47x15	30x55x17	45,-
09-1008	Honda	Honda CLR 125 City Fly (CLR125)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda CR 250 R Cross (ME30)	26x47x15	26x47x15	69,-
09-1006	Honda	Honda CX 500 T TURBO (PC03)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda CX 650 T (RC16)	26x47x15	30x55x17	59,-
09-1005	Honda	Honda GL 1000 K0-K2 (GL1)	25x47x15	30x55x17	45,-
09-1005	Honda	Honda GL 1000 K3 (GL2)	25x47x15	30x55x17	45,-
09-1006	Honda	Honda GL 1100/D (SC02)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda GL 1200 DX (SC14)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda GL 1500 /SE (SC22)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda NT 650 Hawk GT (RC31)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda NT 650 V Deauville (NTV650V)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda NT 650 V Deauville (RC47A)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda NT 700 Deauville (RC52A)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda NTV 650 (RC33)	26x47x15	30x55x17	59,-
09-1008	Honda	Honda NX 250 (MD21)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda NX 650 Dominator (RD02)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda NX 650 Dominator (RD08)	26x47x15	26x47x15	69,-
09-1006	Honda	Honda Pacific Coast (PC-800)	26x47x15	30x55x17	59,-
09-1008	Honda	Honda SLR 650 RC09 (SLR650)	26x47x15	26x47x15	69,-
09-1007	Honda	Honda ST 1100 (SC26)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda ST 1100 CBS/ABS (ST1100ABS)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda ST 1300 Pan European (SC51)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VF 1000 F (SC15)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VF 1000 FII (SC15/1)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VF 1000 R (SC16)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VF 1100 C (SC12)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda VF 500 F/FII (PC12)	26x47x15	30x55x17	59,-

09-1007	Honda	Honda VF 500 F/FII (PC12)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda VF 750 C -C-E-D (RC09)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VF 750 C Magna (RC43)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda VF 750 F (RC15)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VF 750 F (RC15)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda VF 750 S (RC07)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VFR 750 F (RC24)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VFR 750 F (RC24/88)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VFR 750 F (RC36)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VFR 750 F (RC36/94)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VFR 800 (RC46/02)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VFR 800 (RC46/06)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VFR 800 ABS (RC46C)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VFR 800 RC46 (VFR)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VT 1100 C (SC23)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VT 1100 C/C2 (SC32)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VT 1100 C3 (VT1100C3)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VT 500 C (PC08) [BJ 85-86]	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VT 600 C (PC21)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VT 750 C (RC29)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VT 750 C Shadow (RC50)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VT 750 C2 (RC44)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VT 750 DC Black Widow (RC48)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VT 750 SHADOW (RC50/08)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VT 800	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VTR 1000 F (SC36)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda VTX 1300 (SC52)	26x47x15	30x55x17	59,-
09-1006	Honda	Honda VTX 1800 (SC46A) [BJ 01 - 04]	26x47x15	30x55x17	59,-
09-1008	Honda	Honda X4 Bj. '97-'03	26x47x15	26x47x15	69,-
09-1007	Honda	Honda XL 1000 V Varadero (SD01)	26x47x15	30x55x17	59,-
09-1007	Honda	Honda XL 1000 V Varadero (XL1000V/04)	26x47x15	30x55x17	59,-
09-1008	Honda	Honda XL 600 LM/RM (PD04)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda XL 600 R (PD03)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda XL 600 V Transalp (PD06)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda XL 600 V Transalp (PD06/94)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda XL 600 V Transalp (PD10)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda XL650V Transalp (RD10)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda XL650V Transalp (RD10/04)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda XLV 750 R (RD01)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda XR 600 R (PE04)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda XR 600 R (XR600R)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda XRV 650 (RD03)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda XRV 750 (RD04)	26x47x15	26x47x15	69,-
09-1008	Honda	Honda XRV 750 (RD07)	26x47x15	26x47x15	69,-

Kawasaki

09-1000	Kawasaki	Kawasaki standard angular contact ball bearings	35x55x14,5	35x55x14,5	59,-
09-1010	Kawasaki	Kawasaki EN 500 (EN500A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki EN 500 (EN500B1)	25x47x15	28x52x16,5	45,-
09-1001	Kawasaki	Kawasaki ER-6N /F	35x55x14	35x55x14	59,-
09-1010	Kawasaki	Kawasaki GPX 600 R (ZX600A-C)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GPX 600 R (ZX600C)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GPX 750 R (ZX750F)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GPZ 1100 (GP) (KZT10B-A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GPZ 1100 (GP) (KZT10B-B)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GPZ 400 (ZX400A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GPZ 400 UT (KZ400J-M)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GPZ 550 (4Z) (ZX550A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GPZ 600 R (ZX600A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GPZ 750 (ZX750-A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GPZ 750 R (ZX750G)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GPZ 750 UT (ZX750A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GPZ 900 R (ZX900A/1-6)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GPZ 900 R (ZX900A7-10)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GTR 1000 (ZG1000A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki GTR 1000 (ZGT00A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki KLE 500 (KLE500A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki KLE 500 (LE500)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki KLE 500 (LE500A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki KLR 250 (KL250D)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki KLR 600 (KL600A-A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki KLR 600 E (KL600B)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki KLR 650 (KL650A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki KLR 650 (KL650C)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki KLR 650 TENGAI (KL650A-B)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki LTD 450 (EN450A)	25x47x15	28x52x16,5	45,-
09-1001	Kawasaki	Kawasaki Versys	35x55x14	35x55x14	59,-
09-1010	Kawasaki	Kawasaki VN 15 / SE (VNT-50B/C)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki VN 15 SE (VNT50A-B)	25x47x15	28x52x16,5	45,-
09-1001	Kawasaki	Kawasaki VN 1500 DRIFTER (VN1500-J1)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki VN 1600 CLASSIC (VN1600A)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki VN 1700	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki VN 2000/CLASSIC (VNW00)	35x55x14	35x55x14	59,-
09-1010	Kawasaki	Kawasaki VN 750 VULCAN (VN750A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki W 650 (EJ650A1)	25x47x15	28x52x16,5	45,-
09-1001	Kawasaki	Kawasaki Z 1000 (ZR1000-A)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki Z 1000 (ZRT00B)	35x55x14	35x55x14	59,-
09-1010	Kawasaki	Kawasaki Z 1000 J (KZT00J-J)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki Z 1000 LTD (KZT00J-K)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki Z 1000 R (KZT00J-R)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki Z 1100 ST (KZT10A)	25x47x15	28x52x16,5	45,-
09-1011	Kawasaki	Kawasaki Z 1300 (KZT30A)	30x55x17	28x52x16,5	45,-
09-1011	Kawasaki	Kawasaki Z 1300 DFI (ZGT30A)	30x55x17	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki Z 400 FOUR (KZ400J-B)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki Z 550 F (KZ550B-B)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki Z 550 GT (KZ550G)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki Z 550 UT 4Z. (KZ550H)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki Z 750 GP (KZ750E-R)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki Z 750 GT (KZ750E-P)	25x47x15	28x52x16,5	45,-

09-1010	Kawasaki	Kawasaki Z 750 LTD BD 2Z (KZ750B-K)	25x47x15	28x52x16,5	45,-
09-1001	Kawasaki	Kawasaki Z 750 S (ZR750-K)	35x55x14	35x55x14	59,-
09-1010	Kawasaki	Kawasaki Z 750 TURBO (ZX750E)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZEPHYR 1100 (ZR1100B)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZEPHYR 1100 (ZR1100A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZEPHYR 550 (ZR550B)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZEPHYR 550 (ZR550B5)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZEPHYR 750 (ZR750C)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZEPHYR 750 (ZR750D)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZL 1000 (ZLT00A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZL 600 (ZL600A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZR-7 (ZR750-F1)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZR-7S (ZR750F)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZRX 1100 (ZRT10C)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZRX 1200 S/R (ZRT20A)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZX-10 (ZXT00B)	25x47x15	28x52x16,5	45,-
09-1001	Kawasaki	Kawasaki ZX-10R (ZX-10R/04)	35x55x14	35x55x14	59,-
09-1010	Kawasaki	Kawasaki ZX-10R (ZXT00D) [BJ 06]	25x47x15	28x52x16,5	45,-
09-1001	Kawasaki	Kawasaki ZX-10R (ZXT00D) [BJ 07]	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZX-10R NINJA (ZX100E)	35x55x14	35x55x14	59,-
09-1003	Kawasaki	Kawasaki ZX-12R (ZX1200A1H)	25x47x15	35x55x14	45,-
09-1001	Kawasaki	Kawasaki ZX-12R NINJA (ZX1200-B1H) [BJ 03]	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZX-12R NINJA (ZX-12R/04)	35x55x14	35x55x14	59,-
09-1003	Kawasaki	Kawasaki ZX-6R (ZX600-JJ)	25x47x15	35x55x14	45,-
09-1003	Kawasaki	Kawasaki ZX-6R (ZX636-A1H)	25x47x15	35x55x14	45,-
09-1001	Kawasaki	Kawasaki ZX-6R (ZX636B)	35x55x14	35x55x14	59,-
09-1010	Kawasaki	Kawasaki ZX-6R NINJA (ZX600F)	25x47x15	28x52x16,5	45,-
09-1003	Kawasaki	Kawasaki ZX-6R NINJA (ZX600-G1)	25x47x15	35x55x14	45,-
09-1001	Kawasaki	Kawasaki ZX-6R NINJA (ZX636C)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZX-6RR (ZX600K)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZX-6RR (ZX-6RR/04)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZX-7R	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZX-7RR NINJA (ZX750N)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZX-9R NINJA (ZX900B)	35x55x14	35x55x14	59,-
09-1003	Kawasaki	Kawasaki ZX-9R NINJA (ZX900EE)	25x47x15	35x55x14	45,-
09-1003	Kawasaki	Kawasaki ZX-9R NINJA (ZX900EF)	25x47x15	35x55x14	45,-
09-1001	Kawasaki	Kawasaki ZX-9R NINJA (ZX-9R)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZXR 400 (ZX400L)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZXR 400 (ZX400L4)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZXR 400 (ZX400L5)	35x55x14	35x55x14	59,-
09-1010	Kawasaki	Kawasaki ZXR 750 (ZX750H1)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZXR 750 (ZX750H2)	25x47x15	28x52x16,5	45,-
09-1001	Kawasaki	Kawasaki ZXR 750 (ZX750J,K)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZXR 750 (ZX750L-L)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZXR 750 R (ZX750J,K)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZXR 750 R (ZX750L-M)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZXR 750 R (ZX750M2)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZZR 1100 (ZX10D)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZZR 1100 (ZX10D/10G)	35x55x14	35x55x14	59,-
09-1001	Kawasaki	Kawasaki ZZR 1400 (ZXT40A)	35x55x14	35x55x14	59,-
09-1010	Kawasaki	Kawasaki ZZR 600 (ZX600D)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZZR 600 (ZX600E)	25x47x15	28x52x16,5	45,-
09-1010	Kawasaki	Kawasaki ZZR 600 (ZX600E4)	25x47x15	28x52x16,5	45,-
Moto Guzzi					
09-1000	Moto Guzzi	Moto Guzzi standard angular contact ball bearings	35x55x14,5	35x55x14,5	59,-
09-1001	Moto Guzzi	Moto Guzzi various - please check the dimensions of the assembled bearings	35x55x14	35x55x14	59,-
09-1001	Moto Guzzi	Moto Guzzi 1200 Sport 06-07 , BJ 2006 - 2007	35x55x14	35x55x14	59,-
09-1001	Moto Guzzi	Moto Guzzi 1200 Sport 8V 2008	35x55x14	35x55x14	59,-
09-1001	Moto Guzzi	Moto Guzzi Brevia 1100 IE 05-07 , BJ 2005 - 2007	35x55x14	35x55x14	59,-
09-1001	Moto Guzzi	Moto Guzzi Brevia 1200 2007	35x55x14	35x55x14	59,-
09-1001	Moto Guzzi	Moto Guzzi Brevia 850 IE 06-07 , BJ 2006 - 2007	35x55x14	35x55x14	59,-
09-1001	Moto Guzzi	Moto Guzzi Griso V 1100 IE 05-07 , BJ 2005 - 2007	35x55x14	35x55x14	59,-
09-1001	Moto Guzzi	Moto Guzzi Griso V 1200 8V 2007-2008	35x55x14	35x55x14	59,-
09-1001	Moto Guzzi	Moto Guzzi Griso V 850 IE 06-07 , BJ 2006 - 2007	35x55x14	35x55x14	59,-
09-1001	Moto Guzzi	Moto Guzzi MGS-01 Corsa 04-07 , BJ 2004 - 2007	35x55x14	35x55x14	59,-
09-1001	Moto Guzzi	Moto Guzzi Norge 1200 IE , BJ 2006 -	35x55x14	35x55x14	59,-
09-1001	Moto Guzzi	Moto Guzzi Norge 850 07 , BJ 2007 -	35x55x14	35x55x14	59,-
09-1001	Moto Guzzi	Moto Guzzi Stelvio 1200 08 , BJ 2008 -	35x55x14	35x55x14	59,-
MV Agusta					
09-1000	MV Agusta	MV Agusta standard angular contact ball bearings	35x55x14,5	35x55x14,5	59,-
09-1001	MV Agusta	MV Agusta various - please check the dimensions of the assembled bearings	35x55x14	35x55x14	59,-
09-1001	MV Agusta	MV Agusta	35x55x14	35x55x14	59,-
09-1001	MV Agusta	MV Agusta 910 R portale	35x55x14	35x55x14	59,-
09-1001	MV Agusta	MV Agusta F4	35x55x14	35x55x14	59,-
09-1001	MV Agusta	MV Agusta F41000r	35x55x14	35x55x14	59,-
05M-910	MV Agusta	MV Agusta rear axle bearings Repair kit for the bearing of the rear axle. Set including bearings, radial seals, grease and assembly instruction.			159,-
05M-912	MV Agusta	MV Agusta front wheel bearings Bearing set, two sealed wheel bearings for the bearing of the front wheel.			39,-
Suzuki					
09-1005	Suzuki	Suzuki AN 250 BURGMAN (AN250)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki AN 400 BURGMAN (AU)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki AN 400 BURGMAN (BURGM-400)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki AN 400 BURGMAN (BURGMAN400)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki AN 650 BURGMAN (AN650) [BJ 03-09]	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki AN 650 BURGMAN (BU1321)	25x47x15	30x55x17	45,-
09-1004	Suzuki	Suzuki B-KING (WVCR)	30x55x17	30x55x17	45,-
09-1004	Suzuki	Suzuki DL 1000 V-STROM (WVBS)	30x55x17	30x55x17	45,-

09-1009	Suzuki	Suzuki DL 650 V-STROM (DL650V/07)	30x55x17	30x55x17	45,-
09-1009	Suzuki	Suzuki DL 650 V-STROM (WVB1)	30x55x17	30x55x17	45,-
09-1005	Suzuki	Suzuki DR 125 SE (SF44A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki DR 350 S/SH (SK42B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki DR 350 SE (SK42B/95)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki DR 350 SE (SK42B/96)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki DR 500 S (DR500)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki DR 650 R/RU (SP44B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki DR 650 RE/REU (SP45B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki DR 650 RS/RSU (SP42B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki DR 650 RSE/RSEU (SP43B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki DR 750 S/SU BIG (SR41B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki DR 800 S BIG (SR43B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki DR 800 S/SU (SR42B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GN 250 (NJ42A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GN 400 TD (GN400)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GR 650 /X (GP51A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 1000 D (GS1000)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 1000 G (GS100G)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 1000 GL (GS100G-B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 1000 L (GS1000-L)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 1000 S (GS1000-S)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 1100 G (GU71A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 1100 G (GU73A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 450 L (GL51D)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 450, S (T,X) (GS450)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 450E/EU/S/SU (GL51F)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 500 E (WVBK)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 500 E/EU (GM51B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 500 E/EU (GM51B-96)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 550 KATANA (GS550M)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 650 G (GS650G)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 850 G (GS72A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GS 850 L (GS850B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSF 1200 /S (GV75A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSF 1200 /S (WVA9)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSF 1250 BAND. (GSF1250/07)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSF 1250 S BAND (WVCH)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSF 400 BANDIT (GK75B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSF 600 BANDIT (GN77B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSF 600 BANDIT (WVA8)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSF 600 S BAND. (WVA8/S)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSF 600/S BAND. (GN77B/96)	25x47x15	30x55x17	45,-
09-1004	Suzuki	Suzuki GSR 600 (GSR600)	30x55x17	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 1100 E (GS110X-E)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 1100 E,ES (GU71B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 1100 F (GV72C)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 1100 G (GV74A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 1100 L (GS110X-L)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 1100 SZ KAT (GS110XS)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 1100E,EF,ES (GV71C)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 1200 (A311)	25x47x15	30x55x17	45,-
09-1004	Suzuki	Suzuki GSX 1300 R (WVA1)	30x55x17	30x55x17	45,-
09-1004	Suzuki	Suzuki GSX 1300 R HAYA (GSX1300R)	30x55x17	30x55x17	45,-
09-1004	Suzuki	Suzuki GSX 1300 R HAYA (WVCK)	30x55x17	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 1400 (GSX1400/05)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 1400 (JS1BN11) [AB BJ.04-]	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 400 E/S (GK53C)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 400 F KATA. (GS40XF)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 400/L (GS40X)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 550EF/ES/EU (GN71D)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 600 F/FU (AJ)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 600F/FU/FU2 (GN72B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 650 F (WVCJ)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 750 (AE)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 750 E (GS75X-E)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 750 ES/EF (GR72A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 750 F (AK1112)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 750 F (AK1113)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 750 F (GR78A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 750 L (GS75X-L)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX 750 S KATA. (GR71A)	25x47x15	30x55x17	45,-
09-1009	Suzuki	Suzuki GSX-R 1000 K1 (WVBL)	30x55x17	30x55x17	45,-
09-1009	Suzuki	Suzuki GSX-R 1000 K3 (WVBZ)	30x55x17	30x55x17	45,-
09-1009	Suzuki	Suzuki GSX-R 1000 K5 (WVB6) [- BJ.05]	30x55x17	30x55x17	45,-
09-1004	Suzuki	Suzuki GSX-R 1000 K5 (WVB6) [BJ.06]	30x55x17	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX-R 1100 (GU74C/86)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX-R 1100 (GU74C/87)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX-R 1100 (GU74C/88)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX-R 1100 (GV73C/89)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX-R 1100 (GV73C/90)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX-R 1100 (GV73C/92)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX-R 1100 W (GU75C)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX-R 1100 W (GU75C/96)	25x47x15	30x55x17	45,-
09-1009	Suzuki	Suzuki GSX-R 600 (AD3112)	30x55x17	30x55x17	45,-
09-1009	Suzuki	Suzuki GSX-R 600 (BG)	30x55x17	30x55x17	45,-
09-1004	Suzuki	Suzuki GSX-R 600 (CV)	30x55x17	30x55x17	45,-
09-1004	Suzuki	Suzuki GSX-R 600 (WVB2)	30x55x17	30x55x17	45,-
09-1009	Suzuki	Suzuki GSX-R 600 (WVB2)	30x55x17	30x55x17	45,-
09-1004	Suzuki	Suzuki GSX-R 600 (WVCE)	30x55x17	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX-R 750 (GR75A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX-R 750 (GR77B(K))	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX-R 750 (GR77B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX-R 750 (GR7AB)	25x47x15	30x55x17	45,-
09-1009	Suzuki	Suzuki GSX-R 750 (GR7DB)	30x55x17	30x55x17	45,-
09-1009	Suzuki	Suzuki GSX-R 750 (WVB3)	30x55x17	30x55x17	45,-
09-1009	Suzuki	Suzuki GSX-R 750 (WVBD)	30x55x17	30x55x17	45,-
09-1009	Suzuki	Suzuki GSX-R 750 INJ. (GR7DA/DB)	30x55x17	30x55x17	45,-
09-1005	Suzuki	Suzuki GSX-R 750 R (GR79B)	25x47x15	30x55x17	45,-

09-1005	Suzuki	Suzuki GSX-R 750 W(II) (GR7BB)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GZ 125 MARAUDER (AP)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki GZ 250 MARAUDER (AR)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki LS 650 P/F (NP41B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki RF 600 R (GN76B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki RF 600 R/RU (GN76B/96)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki RF 900 RS2/R (GT73B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki RG 250 GAMMA (GJ21A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki RG 500 GAMMA (HM31A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki RGV 250 (VJ21A)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki RGV 250 (VJ22B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki SIXTEEN 125 (SIXT-125)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki SIXTEEN 150 (SIXT-150)	25x47x15	30x55x17	45,-
09-1009	Suzuki	Suzuki SV 1000 (BX)	30x55x17	30x55x17	45,-
09-1005	Suzuki	Suzuki SV 650 (AV)	25x47x15	30x55x17	45,-
09-1009	Suzuki	Suzuki SV 650 /S (WVBY)	30x55x17	30x55x17	45,-
09-1005	Suzuki	Suzuki SV 650 S (AV/S)	25x47x15	30x55x17	45,-
09-1004	Suzuki	Suzuki TL 1000 R (AM) (TL1000R)	30x55x17	30x55x17	45,-
09-1009	Suzuki	Suzuki TL 1000 S (AG) (TL1000S)	30x55x17	30x55x17	45,-
09-1005	Suzuki	Suzuki UH 125 BURGMAN (BH111)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki UH 125 BURGMAN (UH125/07)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki UH 200 BURGMAN (UH200/07)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki VL 1500 INTRUDE (JS1AL)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki VL 800 VOLUSIA (WVBM)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki VS 1400 GLP (VX51L/96)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki VS 1400 INTRU. (VX51L)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki VS 600 GL/GLU (VN51B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki VS 750 GLP/GLF (VR51B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki VS 800 GL (VS52B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki VX 800 / U (VS51B)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki VX 800 / U (VS51B/95)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki VX 800 / U (VS51B/96)	25x47x15	30x55x17	45,-
09-1005	Suzuki	Suzuki VZ 800 MARAUDER (VZ800)	25x47x15	30x55x17	45,-
Yamaha					
09-1005	Yamaha	Yamaha BT 1100 BULLDOG (RP051) [BJ 02-]	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha BT 1100 BULLDOG (RP052)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha DT 125 X (DT125X)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FJ 1100 (47E)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FJ 1200 (1XJ)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FJ 1200 (3CW)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FJ 1200/ABS (3YA)	25x47x15	30x55x17	45,-
09-1004	Yamaha	Yamaha FJR 1300 ABS (RP08)	30x55x17	30x55x17	45,-
09-1005	Yamaha	Yamaha FZ 750 (1FN)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZ 750 (2KK)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZ 750 (3KT)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZ 750 (3KT/93)	25x47x15	30x55x17	45,-
09-1009	Yamaha	Yamaha FZ1 (RN165)	30x55x17	30x55x17	45,-
09-1009	Yamaha	Yamaha FZ1 FAZER (RN161)	30x55x17	30x55x17	45,-
09-1005	Yamaha	Yamaha FZ6 (FZ6)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZ6 (FZ6/07)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZ6 FAZER (FZ6F/07)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZ6 FAZER (FZ6-FAZER)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZR 1000 (2LA)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZR 1000 (3LE)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZR 1000 (3LF) (3LE/94)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZR 600 (3HE)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZR 600 (3RG)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZR 600 (3RH)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZR 600 R (4JH)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZR 600 R (4MH)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZR 750 R (OW01)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZS 1000 FAZER (RN06)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZS 600 FAZER (5DM)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZS 600 FAZER (FZS600)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZS 600 FAZER (RJ02)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha FZX 750 (2JE)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha RD 500 LC (47X)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha RD 500 YPVS LC (1GE)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha SZR 660 (4SU)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha TDM 850 (3VD)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha TDM 850 (4CM)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha TDM 850 (4TX)	25x47x15	30x55x17	45,-
09-1004	Yamaha	Yamaha TDM 900 (RN08)	30x55x17	30x55x17	45,-
09-1004	Yamaha	Yamaha TDM 900 (TDM900/04)	30x55x17	30x55x17	45,-
09-1004	Yamaha	Yamaha TDM 900 A (TDM900A)	30x55x17	30x55x17	45,-
09-1005	Yamaha	Yamaha TRX 850 (4UN)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha TT 350 S (1TJ)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha TT 600 (36A)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha TT 600 N (59X)	25x47x15	30x55x17	45,-
09-1002	Yamaha	Yamaha TT 600 R (TT600R)	28x52x16,5	28x52x16,5	45,-
09-1005	Yamaha	Yamaha TZR 125 (4FL)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha VMAX (2WE) (2EN)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJ 600 S/N (4BR)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJ 600 S/N (4EB)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJ 600 S/N (4LX)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJ 600 S/N (RJ01)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJ 750 (41Y)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJ 900 (31A)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJ 900 / F (58L)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJ 900 F (4BB)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJ 900 S (4KM)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJR 1200 (4PU)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJR 1200 SP (XJR1200SP)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJR 1300 (RP02)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJR 1300 (RP06)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XJR 1300 (RP10)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XS 1100 (2H9)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XS 1100 (3X0)	25x47x15	30x55x17	45,-

09-1005	Yamaha	Yamaha XS 1100 S (5K7)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XS 750 (1T5)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XS 750 SE (3L3)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XS 850 (4E2)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 350 (1WM)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 350 (3YT)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 350 (55V)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 350 (59Y)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 550 (28E)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 550 (5Y3)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 600 (2KF)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 600 (2NF)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 600 (43F)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 600 E/K (3TB)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 600 E/K (3UW)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 600 Z (1VJ)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 600 Z (34L)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 600 Z (3AJ)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XT 600 Z (55W)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XTZ 660 (3YF)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XTZ 660 (4MD)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XTZ 660 TÉNÉRÉ (4MY)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XTZ 750 TÉNÉRÉ (3LD)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XTZ 750 TÉNÉRÉ (3WM)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XV 1000 VIRAGO (2AE)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XV 1600 WILD ST (VP08)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XV 750 SE (5G5)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XV 750 VIRAGO (4FY)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XV 750 VIRAGO (4PW)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XVS 1100 D.STAR (VP05)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XVS 650 DRAG ST (4VR)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XVS1100 D.S.CL. (VP16)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XVZ 12 T (47G)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XVZ 13 TD (3JS)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha XVZ 1300A ROYAL (4NK)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha YZF 1000 R (4VD)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha YZF 600 R (4TV/4WD)	25x47x15	30x55x17	45,-
09-1005	Yamaha	Yamaha YZF 750 R (4HN)	25x47x15	30x55x17	45,-
09-1004	Yamaha	Yamaha YZF-R1 (RN01)	30x55x17	30x55x17	45,-
09-1004	Yamaha	Yamaha YZF-R1 (RN04)	30x55x17	30x55x17	45,-
09-1004	Yamaha	Yamaha YZF-R1 (RN042)	30x55x17	30x55x17	45,-
09-1004	Yamaha	Yamaha YZF-R1 (RN09)	30x55x17	30x55x17	45,-
09-1004	Yamaha	Yamaha YZF-R6 (RJ031)	30x55x17	30x55x17	45,-
09-1004	Yamaha	Yamaha YZF-R6 (RJ031/01)	30x55x17	30x55x17	45,-
09-1004	Yamaha	Yamaha YZF-R6 (RJ031/RJ05)	30x55x17	30x55x17	45,-
09-1004	Yamaha	Yamaha YZF-R7 (OW02)	30x55x17	30x55x17	45,-

Advice for measuring of the dimensions of the standard steering head bearings

The dimensions of the standard steering head bearings (angular contact ball bearings) can only be determined in case the bearings are completely disassembled. The height of the bearing must be measured as total height (inner- / outer ring) on the complete bearing. The height of a single bearing ring is smaller than the total height of the bearing.




Figure:
Angular contact ball bearing, inner diameter d, outer diameter D and total height H

Note:

Please respect that text, layout and pictures of this catalogue are protected by copyright and are notarized. Any publication or use without our explicit consent we regrettably have to forbid.